

SET/RECALL OR DONE
(To save changes and exit setting)

MODE OR NEXT
(Proceed to next step)



INDIGLO® Button

START/SPLIT OR +
(Increase value. Hold to increase rapidly)

STOP/RESET OR -
(Decrease value. Hold to decrease rapidly)

SET/RECALL OR DONE
(To save changes and exit setting)

MODE OR NEXT
(Proceed to next step)



INDIGLO® Button

STOP/RESET OR -
(Decrease value. Hold to decrease rapidly)

When setting, each button has a different function as indicated above. Watch face will indicate when button changes function.

TIME/DATE/HOURLY CHIME

1. In TIME mode, press and hold SET/RECALL. Time zone will flash.
2. To set, push + or – to select first or second time zone.
3. Press NEXT. Hour digits flash.
4. Press + or – to change hour including AM/PM. (Scroll through 12 hours to get to AM/PM).
5. Press NEXT. Minute digits flash.
6. Press + or – to change minutes.
7. Press NEXT. Second digits flash.
8. Press + or – to set seconds to zero.
9. Continue pattern to set month, day of month, year, 12-hour or 24-hour time display, MM.DD or DD.MM date format, turn hourly CHIME on/off, turn BEEP on/off. If you select BEEP on, a beep will sound every time you push a button (except INDIGLO®).
10. Press DONE to confirm and exit or NEXT to continue and set second time zone, if desired.
11. When in Time mode, press and hold START/SPLIT to “peek” at second time zone; hold for 4 seconds to switch time zones.